

UNIVERSAL MANUAL · ENTIRE CATEGORY

INSTRUCTIONS FOR USE

Anal Toys

This document is the **universal manual for the entire product category, Anal Toys** (anal plugs, anal beads, anal chains, prostate stimulators, inflatable toys, and other variants). It contains safety, usage, and care information common to the entire category.

SAFE MATERIALS

DISCREET PACKAGING

EASY CARE



Category
Anal Toys

Document type
Universal manual

Contents

01	Safety information	3
02	First use	4
03	Usage	5
04	Optional features by model	6
05	Charging & battery	7
06	Care & cleaning	8
07	Storage	9
08	Troubleshooting	10
09	Disposal & recycling	11
10	Responsible person & contact	12



IMPORTANT

Keep all of this information for safe and correct use. Also keep the product packaging, as it contains the instructions for use and information about the product, batteries, and charging. For more information, scan the QR code on the packaging.



Your safety is our top priority. Before using the product, carefully read and follow all the instructions below.

- Keep out of reach of children, as small parts could be swallowed.
- Use the product only if you are in good physical condition.
- Do not use the product with other people against their will. Use the product only with the consent of all persons involved.
- Use the product safely to avoid injury. Use the product at your own risk.
- If a person has any health problems or concerns, they should consult a doctor before using the product.
- Do not use the product on sick or irritated skin.
- If unpleasant skin irritation or physical discomfort occurs, stop using the product immediately. If symptoms persist, consult a doctor.
- To prevent illness and infection, do not pass the product on to third parties.
- Carefully read the information on the product packaging to avoid allergic reactions (e.g. to latex).
- Do not use the product if it is visibly not working, overheating, or has visible defects.
- Do not freeze or heat the product.
- The product is not suitable for commercial use.
- Do not inflate inflatable products beyond the diameter stated on the packaging.
- The product is not suitable for medical use.
- Only charge the product using a suitable charger in an electrical outlet. Follow the instructions for the relevant power adapter.

**WARNING**

No liability can be accepted for damage or accidents caused by improper use, use of force, modifications, or failure to follow these safety instructions.



- Before first use, clean the product with warm water and mild soap. To prevent damage to the device, make sure water does not get into the battery compartment. Do not immerse the device in water.
- Charge the product or insert batteries (if included). For safety reasons, lithium batteries are usually charged to only 40–50% for transport.
- First turn the product on. Then insert it into the rectum.

**IMPORTANT**

To avoid injury or tearing of the sphincter muscle during insertion, gently pre-stretch the sphincter muscle before anal intercourse. Initially use only toys with a smaller diameter and increase the size carefully.

1

Apply lubricant

Apply a sufficient amount of lubricant to the surface of the product. Important: we recommend using a water-based lubricant. Important: to avoid pain during insertion, injury, or tearing of the sphincter, use a sufficient amount of lubricant.

2

Turn on vibration (if applicable)

To start the vibration, turn the product on using the control unit.

3

Get into a comfortable position

To achieve a comfortable position for inserting the product, lean forward onto all fours, or lie on your back with a pillow under your buttocks, or squat over the product.

4

Insert the product

Slowly insert the product into the rectum. Important: there are two muscular rings in the rectum that the product must pass through during insertion — proceed slowly and carefully, and if necessary, loosen the anal opening beforehand with circular finger movements. Important: the pull-out handle or base prevents the product from being fully inserted into the rectum. Anal vibrators do not have a stopper — always hold them firmly.

5

Adjust the intensity (if applicable)

To change the vibration settings, carefully press, turn, or slide the control unit.

6

Remove the product

Slowly remove the product from the body using the pull handle.

7

Turn off vibration (if applicable)

Press, turn, or slide the control unit back to its starting position. Important: if the product switches off automatically when the battery is depleted, do not turn it on again — instead charge it using an electrical outlet.



The following features apply only to selected models — check which functions your specific product offers.

- Some anal toys are also suitable for vaginal use. After every anal use, clean the product thoroughly before continuing with vaginal use.
- Some anal toys have special functions (e.g. rotation, pressure function, pump function). Press the control unit to turn these functions on and off.
- Some anal toys have a pump bulb. To increase the diameter of the anal toy, repeatedly squeeze the pump bulb as needed. The anal toy will inflate. To release the air, open the valve.
- Some anal toys have a suction cup that allows the product to be attached to a smooth, clean, and dry surface. Carefully detach the suction cup from the surface.



The following principles apply to rechargeable and battery-powered models in this category (vibrating anal toys).

- Only charge the product using a suitable charger in an electrical outlet. Follow the instructions for the relevant power adapter.
- Charge the product or insert batteries (if included). For safety reasons, lithium batteries are usually charged to only 40–50% for transport — so fully charge the product before first use.
- If the product switches off automatically when the battery is depleted, do not turn it on again — instead charge it using an electrical outlet.
- To extend the life of batteries and rechargeable batteries and prevent damage to the product, remove the batteries from the product after each use, or unplug the product as soon as the rechargeable battery is fully charged.



- After each use, let the product cool down before putting it away.
- After each use, clean the product with warm water and mild soap, and disinfect it with a disinfectant solution suitable for the product. To prevent damage to the product, make sure water does not get into the battery compartment. Do not immerse the device in water.



- Store the product in a clean, cool, and dry place. Moisture can damage the batteries and motor. Avoid direct sunlight.
- To prevent chemical reactions, store the product separately and not together with other products made of different materials.

**The product is difficult to insert.**

Use a sufficient amount of water-based lubricant and proceed slowly — see the “Usage” chapter. Initially choose a smaller diameter.

The vibration does not work (for vibrating models).

Check the battery charge level according to the “Charging & battery” chapter.

The product does not come out easily after use.

Stay calm, relax the sphincter muscle, and slowly pull the product out by the handle or base — never pull with force.

The anal toy does not inflate (for models with a pump bulb).

Check that the valve is closed, and repeatedly squeeze the pump bulb — see the “Optional features by model” chapter.

**CAUTION**

If the problem persists even after trying the steps above, stop using the product and contact Lechtivo.cz customer support.

Do not throw away packaging material or old devices. If possible, recycle the items. Separate packaging by material and dispose of it together with household waste. Do your part to protect the environment and hand over old devices at local collection points in accordance with national legal regulations and applicable guidelines. Before handing over old devices at a collection point, remove any loose batteries and rechargeable batteries from them. Before disposing of old devices, make sure you have deleted all personal data from them.

Electronic waste

- The crossed-out wheeled bin symbol means that this product must be handed in free of charge at an electronic waste collection point so that it can be recycled for the best possible reuse of raw materials.

Batteries

- Batteries do not belong in household waste. As a consumer, you are legally required to hand in used batteries at public collection points or at places where batteries are sold.
- Batteries containing hazardous substances are marked with a symbol and one of the chemical symbols: Cd (cadmium), Hg (mercury), Pb (lead).
- Lithium batteries and battery packs may only be handed in at collection points if they are discharged. To prevent short-circuiting, insulate the terminals (e.g. with adhesive tape) before handing them in.



ENVIRONMENT

By recycling, you contribute to protecting the environment and to the best possible reuse of raw materials.

**Lechtivo customer contact**

E-mail: info@lechtivo.com · Web: www.lechtivo.com

Responsible person in the EU

Milan Macík
Mivatora s.r.o.
Hlubočepská 1287/2a
152 00 Praha 5

**ONLINE VERSION**

You can find the current version of this manual at www.lechtivo.com.