

UNIVERSAL MANUAL · ENTIRE CATEGORY

INSTRUCTIONS FOR USE

Masturbators – With Functions

This document is a **universal instruction manual valid for the entire product category of masturbators with functions** (masturbators with vibration, rotation, pressure, pumping, or suction functions). It contains common safety, usage, and care information applicable across the entire category.

SAFE MATERIALS

DISCREET PACKAGING

EASY CARE



Category
Masturbators – With Functions

Document type
Universal manual

Contents

01	Safety information	3
02	First use	4
03	Using masturbators	5
04	Optional features by model	6
05	Charging & battery	7
06	Care & cleaning	8
07	Storage	9
08	Troubleshooting	10
09	Disposal & recycling	11
10	Responsible person & contact	12



IMPORTANT

Please keep all of this information for safe and correct use. Also keep the product packaging, as it contains the instructions for use and information about the product, batteries, and charging. For more information, scan the QR code on the packaging.



Your safety is our top priority. Before using the product, please read and follow all the instructions below carefully.

- Keep out of reach of children, as small parts may be swallowed.
- Use the product only if you are in good physical condition.
- Do not use the product with other people against their will. Use the product only with the consent of everyone involved.
- Use the product safely to avoid injury. Use the product at your own risk.
- If a person has any health problems or concerns, they should consult a doctor before using the product.
- Do not use the product on sick or irritated skin.
- If unpleasant skin irritation or physical discomfort occurs, stop using the product immediately. If symptoms persist, consult a doctor.
- To prevent illness and infection, do not pass the product on to third parties.
- Read the information on the product packaging carefully to avoid allergic reactions (e.g. to latex).
- Do not use the product if it is clearly malfunctioning, overheating, or has visible defects.
- Do not freeze or heat the product.
- The product is not suitable for commercial use.
- Do not inflate inflatable products beyond the diameter stated on the packaging.
- The product is not suitable for medical use.
- Charge the product only with a suitable charger in an electrical outlet. Follow the instructions for the relevant power adapter.

**WARNING**

No liability can be accepted for damage or accidents caused by improper use, use of force, modifications, or failure to comply with these safety instructions.



- Before first use, clean the product with warm water and mild soap. To avoid damaging the device, make sure no water gets into the battery compartment. Do not submerge the device in water.

If applicable:

- Charge the product or insert batteries (if included). For safety reasons, lithium batteries are usually charged to only 40–50% for transport.
- First turn the product on. Then insert it into the vagina or place it on the desired area of the genitals.
- Before use, assemble the individual parts of the product.

1

Remove the cap

If necessary, remove the cap from the product's opening.

2

Position the vibrator

If applicable, place the vibrator into the recess designed for it.

3

Apply lubricant

Apply a sufficient amount of lubricant to the sleeve and opening of the product as well as to the penis. Important: a water-based lubricant is recommended.

4

Insert the product

Insert the erect penis into the product.

5

Stimulate with movement

Move the product up and down so the internal structure stimulates your penis. Important: to increase friction on the penis, you can hold the sleeve more firmly — this reduces the internal diameter.

6

Turn on the vibrations

To start the vibrations, turn on the product using the control unit.

7

Adjust the intensity

To change the vibration settings, carefully press, turn, or slide the control unit.

8

Turn off the vibrations

Press, turn, or slide the control unit back to its starting position. Important: if the product switches off automatically when the battery is depleted, do not turn it on again — charge it at an electrical outlet instead.

9

Remove the product

Slowly remove the product from the penis.



Depending on the specific model, your product may be equipped with one of the following functions:

- Some masturbators can be used on both sides and have two openings you can penetrate.
- Some masturbators have a special function (e.g. rotation, pressure function, pump function). Press the control unit to turn these functions on and off.
- Some masturbators have a pump bulb. Squeeze the pump bulb, repeatedly if necessary, to increase friction on the penis — the sleeve will inflate and the internal diameter of the masturbator will decrease.
- To increase the vacuum inside the product, partially or fully close the opening at the other end of the product with your finger, or turn the cap at the other end of the product.
- Some masturbators have a suction cup that lets you attach the product to a smooth, clean, and dry surface. Then carefully detach the suction cup from the surface.
- Some masturbators have a moaning-sound function via headphones. Make sure the volume is not set too high.



The following rules apply to rechargeable and battery-powered models in this category.

- Charge the product only with a suitable charger in an electrical outlet. Follow the instructions for the relevant power adapter.
- Charge the product or insert batteries (if included). For safety reasons, lithium batteries are usually charged to only 40–50% for transport — fully charge the product before first use.
- If the product switches off automatically when the battery is depleted, do not turn it on again — charge it at an electrical outlet instead.
- To extend the life of batteries and rechargeable batteries and to prevent damage to the product, remove the batteries from the product after each use, or unplug the product once the rechargeable battery is fully charged.



- After each use, let the product cool down before putting it away.

Clean the product after each use. Proceed as follows:

1. If necessary, remove the sleeve from the housing.
 2. If applicable, remove the vibrator.
 3. You may need to turn the sleeve inside out.
 4. Lather the surface with mild soap.
 5. Rinse the surface with warm water. Important: to avoid damaging the device, make sure no water gets into the housing.
 6. Dry the surface with a lint-free cloth.
 7. If necessary, disinfect the surface and dry it again.
 8. If applicable, return the sleeve to its original position and repeat steps 4 to 6.
 9. If applicable, clean the other parts of the product. Make sure no water gets into the housing.
- To protect and preserve the sensitive surface of the sleeve, apply a care powder after drying.



- Store the product in a clean, cool, and dry place. Moisture can damage the batteries and motor. Avoid direct sunlight.
- To prevent chemical reactions, store the product separately and not together with other products made of different materials.



The product slides too much or catches when inserting.

Apply more water-based lubricant as described in the “Using masturbators” chapter.

The vibrations do not work or are weak.

Check the battery charge level as described in the “Charging & battery” chapter.

Friction inside the product is too weak.

For models with a pump bulb or cap, increase the vacuum/friction as described in the “Optional features by model” chapter.

The suction cup does not hold onto the surface.

Make sure the surface is smooth, clean, and dry, as described in the “Optional features by model” chapter.



NOTICE

If the problem persists even after trying the steps above, stop using the product and contact Lechtivo.cz customer support.

Do not throw away packaging material or old devices. If possible, recycle the items. Sort packaging by material and dispose of it together with household waste. Do your part to protect the environment and hand in old devices at local collection points in accordance with national laws and applicable guidelines. Before handing in old devices at a collection point, remove any loose batteries and rechargeable batteries from them. Before disposing of old devices, make sure you have erased all personal data from them.

Electronic waste

- The crossed-out wheeled bin symbol means that this product must be handed in free of charge at an electronic waste collection point so it can be recycled for the best possible reuse of raw materials.

Batteries

- Batteries do not belong in household waste. As a consumer, you are legally required to hand in used batteries at public collection points or at places where batteries are sold.
- Batteries containing hazardous substances are marked with a symbol and one of the chemical symbols: Cd (cadmium), Hg (mercury), Pb (lead).
- Lithium batteries and battery packs may only be handed in at collection points if they are discharged. To prevent short-circuiting, insulate the terminals (e.g. with adhesive tape) before handing them in.



ENVIRONMENT

By recycling, you contribute to protecting the environment and to the best possible reuse of raw materials.

**Lechtivo customer contact**

E-mail: info@lechtivo.com · Web: www.lechtivo.com

Responsible person in the EU

Milan Macík
Mivatora s.r.o.
Hlubočepská 1287/2a
152 00 Praha 5

**ONLINE VERSION**

You can find the current version of this manual at www.lechtivo.com.